




Thermal overload relay
Nadprúdové relé
Nadprúdové relé
Przełącznik przeciążeniowy
Releu termice
Motorschulzrelai
Relaysthermique
Реле перегрузки
Термична заштита
Bimetal

IEC/EN 60947-4-1

Mounting instructions

Montážní návod

Montážne inštrukcie

Instrukcja montazu

Instrucțiuni de asamblare

Montageanweisung

Instructions de montage

Инструкция по монтажу

Monteringsanvisning

Istruzioni di montaggio

Instrucciones de montaje

Összeszerelési útmutató

Asennusohjeita

Montage-instructies

Instruções de montagem

Navodila za montažo

Οδηγίες Εγκατάστασης

Инструкции за инсталиране

Monteringsvejledningen

Montažu upute

Surinkimo instrukcijos

Instalēšanas instrukcijas

Скупштина упутство

Päigaldusjuhendid

Caution: Installation by electricians only

Varování: Montáž pouze osobou s elektrotech. kvalifikací

Varovanie: Montáž iba osobou s elektrotech. kvalifikáciou

Uwaga: Montaż tylko przez uprawnionych instalatorów

Atenție: Instalare numai de către electricieni




Vorsicht: Montagenur durch Elektrofachkräfte

Attention: Montage uniquement par un électricien



Осторожно: Монтаж только электрика

NOARK

A






CLICK!




Automatic

Manual


CLICK!




B



C



D



E

	M4 2.5N·m		 1~10 mm²	 1~10 mm²	 1~10 mm²	 1~10 mm²	 1~10 mm²	 1~10 mm²	 1~10 mm²	 1~10 mm²
			 1~2.5 mm²	 1~2.5 mm²	 1~2.5 mm²	 1~2.5 mm²	 1~2.5 mm²	 1~2.5 mm²	 1~2.5 mm²	 1~2.5 mm²



Printed with environmentally-friendly paper
Copyright Noark.All Rights Reserved

NOARK

Z9R38201212EU

Do not hesitate to contact us if you have any questions

phone: +98 9300678767

www.zavoshelectric.ir